Boat Equipment & Fixtures

General

This section details what boat equipment and fixtures you should check (for) when preparing the boats for use. There are three lists. They all refer to a standard Sea Scout Cutter, but are also generally applicable when making use of the sunbursts.

Boat Equipment & Fixtures:

- 1. For all boating activities,
- 2. When going rowing, and
- 3. When going sailing.

Boat Trailers

The easiest way to transport our boats is through the use of a vehicle towing a trailer with the boat on it, as the boats tend to be very heavy to carry.

The following outlines the items you should check with respect to the boat trailers.

- The boat should be tied down, and fastened to the winch cable.
- The light board should be tied on, plugged in, and checked that it is working.
- The light board should carry a current WOF and registration sticker.
- The safety chain between the towing vehicle and trailer should be securely fastened.
- A spare wheel and trailer jack should be carried.
- 2 chocks for blocking the wheels when launching or retrieving the boat.

Other Gear

Boat Box

• Contains items for undertaking running repairs on the boats.

First Aid Kit

- You may find some useful items in one of these if you get hurt.
- Do you know what should be in a First Aid Kit and how to use its contents?

Boat Equipment & Fixtures For All Boating Activities

when going boating.

General The following equipment should always be carried in the Sea Scout Cutter

Anchor	 Anchor warp to be 30 metres long, Either 3 m of 8 mm chain, or 5.2 m of 6 mm chain, Ensure that the anchor is securely fastened to the boat, and that it is not tangled so that it can be used.
Bailers	 1 * 9 litre, 1 * 3 litre, Must be tied in, with cordage of sufficient length for easy use.
Boat Hook	Used when picking up buoys.
Bung	Ensure that you have the correct bung and that it is in place.
Buoyancy	Ensure any removable buoyancy is present and securely fastened in.
Crutches	6 + 1 spare,Must be tied in.
Floor boards	Ensure that any floor boards are securely fastened in.
Life Jackets	 1 for each crew member, You do not have to wear a life jacket when rowing but they must be carried in the boat.
Life Ring	 Should be clearly marked with the boat and group name, Should be easily accessible.
Oars	Two oars should be carried at all times.
Painters	 Stern Painter, Forward Painter, Both must be tied in and should be at least the length of the boat. Used for: Towing Being towed Tying up alongside
Rudder & Tiller	 Makes steering the boat much easier. Include both rowing and sailing tillers. If one breaks you have a spare.

Boat Equipment & Fixtures When Going Rowing

General	In addition to those items listed under 'Boating Equipment & Fixtures For All Boating Activities', the following equipment should always be carried when going rowing.
Oars	One oar for each crew member, plus one spare oar. (Includes the two oars already in the boat).
Stretchers	Makes rowing much easier.

Boat Equipment & Fixtures When Going Sailing

General

In addition to those items listed under 'Boating Equipment & Fixtures For All Boating Activities', the following equipment should always be carried when going sailing.

Battens	The Main sail requires battens to give it shape.
Boom	Make sure you have the correct boom for the boat you are using.
Buoyancy	Ensure that any additional buoyancy required (usually for under the thwarts), is present and securely fastened in.
Mast	Make sure you have the correct mast for the boat that you are using and that it is securely tied down.
Reefing Cord	Cord to reduce sail area in heavy winds.
Rigging	 Ensure that you have: Side stays (2) A fore stay (1) Back stays (2) A haliad for each sail Sheets for each sail
Sails	 The boats can carry the following sails: Main sail Jib Spinnaker
Spinnaker Pole	A very useful item if planning on using the spinnaker.